

How to install Winter Kit for TurnSys systems.



1. The Winter Kit for TurnSys is compatible with all Lazer TurnSys system helmets.

2. To install the Winter Kit, you must first remove all of the original padding from the helmet.



3. Pull the padding pieces out of the helmet while carefully avoiding also pulling off the Velcro sticky pads.

4. Repeat steps to remove all pieces of padding.



5. Then place the Winter Kit inside the helmet shell with the flap at the back ensuring it's centrally aligned with the helmet.

6. Align the front edge of the Winter Kit with the brim of the helmet and evenly push the Winter Kit into the helmet to attach it.



7. Then thread the helmet strap through the retention strap on the Winter Kit's earpiece. Repeat this on the other side.

8. The flap at the back should fit over the fit system dial.



9. To do this first extend the fit system to the largest vertical adjustment by pulling the rear head basket away from the helmet

How to install Winter Kit for TurnSys systems.



10. Then fold the flap over the dial so the dial pops through the hole.



11. Push the flap firmly around the dial on each side to create a snug fit.



12. These steps are the same for the Lazer TurnSys fit systems which are integrated with the Universal LED direct mount bracket.

13. Reposition the head basket to preferred vertical fit.

14. You're now ready to ride through the winter!

